



Part List

- mechanical -



Sony Ericsson Live with Walkman

WT19a, WT19i



CONTENTS













1	Part List	3
2	Revision History	8

















1 Part List

















The following parts are available for order in 'E-star'.

















The 'E-star' name of a part may often be complex and even confusing, so the name of certain parts mentioned in the Working Instructions, Repair Movies and Troubleshooting Guide are often referred to by a simple descriptive name for better understanding.

















Both names (designations) will in that case be included in this Part List, where the name being used in the documents mentioned above is underlined, e.g. Battery Cover.

Designation	Part No.	Part	Location
Adhesive Audio Jack	1251-5755		
Adhesive Camera Window	1251-5757		
Adhesive LCD FPC	1253-3505		
Adhesive Touch Panel	1253-3506		
Audio Jack	1249-5014		
<u>Battery Cover</u> Battery Cover Assy Black Battery Cover Assy White	1250-4681 1250-5897		

Designation	Part No.	Part	Location
<u>Camera</u> Camera 5.1 MPixel CMOS	1230-6587		
Camera Ring	1250-4689		
Carrier Frame Assy	1250-4702		
<u>Co-Brand</u> Co-Brand Black Co-Brand White Co-Brand Black China Unicom Co-Brand White China Unicom	1250-5005 1250-5899 1254-7357 1254-7358		
Core Unit Label	1250-4745		
Cushion 0.0 mm Rubber Camera	1250-4719		
Cushion PBA	1253-3537		
Cushion PBA B	1251-8040		

Designation	Part No.	Part	Location
<u>Display</u> Display 3.2 inch A-SI TFT	1249-1273		
Doom Sheet	1250-4619		
<u>Ear Speaker</u> Ear Speaker 15.0 Rectangular	1231-4565		
<u>Front Cover</u> Front Cover Assy Black Front Cover Assy White	1253-7477 1253-7817		
Gasket Camera	1250-4698		
Gasket Receiver	1251-2275		
Gasket Speaker	1251-5751		
<u>Icon Walkman Logo</u> Icon Walkman Logo Green Icon Walkman Logo Orange	1251-2286 1251-7881		

Designation	Part No.	Part	Location
<u>Key Home</u> Key Home Black Key Home White	1250-5770 1250-5894		
Key Side	1250-4691		
Label For RF Connector	1251-2276		
<u>Loudspeaker</u> Loudspeaker 11x15	1001-0324		
Net Microphone	1251-5616		
Net Receiver	1250-4705		
<u>Rear Cover</u> Rear Cover for Band 125 Rear Cover for Band 18	1250-4663 1250-5896	 	 

Designation	Part No.	Part	Location
Screw M1.4x3.5	1204-8506		
Screw Other Len:4.5 Diam:1.7	1223-6144		
Shield Can Lid DBB	1244-9425		
Shield Can Lid PMU	1250-8130		
Shield Can Lid RF	1241-3501		
Water Indicator	1239-5490		
Window Camera	1250-4699		
Window Flash LED	1250-5789		



2 Revision History

Rev.	Date	Changes / Comments
1	2011-Sep-26	Initial release