



INVISION™



Quick Start Guide

Use your phone for more than just talking.

- AT&T Mobile TV
- AT&T Mobile Music
- 1.3 Megapixel Camera with Video
- Video Share
- Mobile Messaging

See User Manual for Spanish instructions.

Additional charges may apply. Visit att.com for more details. Phone features subject to change without prior notice. All phone screens are simulated. Services may not be available in all markets.

AT&T marks contained herein are trademarks of AT&T Intellectual Property and/or AT&T affiliated companies. © 2008 AT&T Intellectual Property. All rights reserved.




Getting to Know Your Phone

For more information, visit att.com/DeviceSupport.




AT&T Mobile TV



Tune in 24/7 for full-length, broadcast-quality episodes of your favorite TV shows on the networks you love.




1. From standby mode, press the **tv Key**.
2. An introductory video clip will play the first time you access this feature.
3. Press **Ⓜ** to select **Subscribe Now**.
4. After reviewing the base package, press the **Left Soft Key** for **Continue**.
5. If you agree to the Terms of Service, press the **Right Soft Key** for **Agree**.
6. Press the **Left Soft Key** for **Submit** to confirm your selection.
7. The TV player will launch. You can access the Program Guide to see what's playing.



Note: All programming subject to change. All sports programming subject to blackout restrictions. Images shown on this page are generic and not representative of the service.

AT&T Mobile Music

AT&T Mobile Music provides the ultimate music experience. Listen to your favorite music, watch the latest music videos, and stay in the know with music news and more.



- From standby mode, press the **Left Soft Key** for **Menu** and select **AT&T Music (6)**.
- Browse and select music from leading digital music stores like Napster® and eMusic™ with **Shop Music**.
- Listen to your music on an integrated **Music Player**.
- Enjoy dozens of commercial-free music stations with **XM Radio**.
- Watch the latest music videos under **Music Videos**.
- Personalize with ringtones and Answer Tones™ under **Shop Music**.
- Instantly ID the title and artist of a song with **MusicID**.
- Get the latest music news, charts, and concert info from **The Buzz**.



*microSD card and USB data cable sold separately; go to att.com/wireless.



Steps may vary depending on Windows Media Player version. **Warning! Do not disconnect phone while file transfer is in progress.

Requirement: Windows Media® Player 10 or higher. Not compatible with Mac OS or iTunes.




Transfer Music



Your phone is not just for talking. You can also listen to music from your favorite artists on your phone. Transfer your favorite tunes today.

1. Make sure your music is in MP3, WMA, AAC, AAC+/eAAC+, or RA format.
2. Insert the microSD™ card* (gold contacts facing down) into the port on the left side of the phone.
3. Connect the phone to your PC using a USB data cable.*
4. Once the Portable Device screen pops up on your PC, select the second option and click **OK**.
5. From within Windows Media Player, songs will populate the left side of the screen. Your **CB630 Music Sync Player** should be the destination for the songs on the right side of the screen.
6. Check/drag** songs to be transferred, then click the **Start Sync** button.
7. When finished, unlock the phone and press the **Right Soft Key** to exit music sync. Select **Yes**, and then disconnect the USB cable.

Play Music


Listen to music from your favorite artists right on your phone. To listen to music that you have transferred to your phone, follow these quick and easy steps.




1. Insert the microSD™ card* (gold contacts facing down) into the port on the left side of your phone.
2. From standby mode, press the **Left Soft Key** for **Menu**, then select **AT&T Music (6)** and **Music Player (1)**.
3. Select **All Songs (1)**, **Playlists (2)**, **Artists (3)**, **Albums (4)**, or **Genres (5)**. With a song selected, press .
4. Press  to play/pause. Press **up** or **down** on the **Volume Keys** to adjust the volume. Press **left** or **right** on the **Navigation Key** to skip to the previous or next song.
5. Press the **Left Soft Key** for **Minimize** to access other phone functions while music is playing.
6. Press the **End Key** to exit the music player.


*microSD card sold separately; go to att.com/wireless.

CV





CV brings your phone to life. Watch news, sports, weather, and entertainment clips while on the go.

1. From standby mode, press the **Right Soft Key** for **Options**, then select **CV - Video (3)** from this customizable menu.
2. Once connected, highlight the video clip you want to play and press .




Personalize your CV Home Page

1. From the CV home page, press  to select **EDIT**.
2. Select the content you would like added or deleted from your CV home page and press .



Note: Parental Controls available. See box insert for details. Access to CV requires a MEdia™ Max plan.


Camera/Video





Capture everything around you in vivid detail via the 1.3 megapixel camera with video and share it instantly.

Take a Picture

1. From standby mode, press the  **Key**.
2. Press **left** or **right** on the **Navigation Key** to adjust the brightness and **up** or **down** to zoom.*
3. Press  to take the picture. Press the **Left Soft Key** to send it to someone.




Record a Video

1. Press and hold the  **Key**, then select **Record Video (2)**.
2. Press  to start/stop recording.

*Camera setting of 1280 x 960 resolution does not support zoom.


Note: From standby mode, press **left** on the **Navigation Key** to see your pictures and videos.

Video Share™



Share events the moment they happen. Video Share lets you stream live video directly to friends and family.

Make a Video Share Call

1. Dial the 10-digit number of another 3G Video Share capable device.*
2. Once the call is answered, press the  **Key** to initiate a Video Share session.



Accept a Video Share Call



1. When receiving a Video Share call, the name or number of the person who wants to share video with you will appear on your screen.
2. Press the **Left Soft Key** for **Accept** and the Video Share session will begin automatically.




To end a Video Share session and continue with the phone call, press the **Left Soft Key** for **Stop**.

*Video Share is not available in all markets. Both parties must be in a 3G service area – a 3G icon must appear by the signal bars prior to a call being placed, and both parties must remain in the 3G coverage area for the duration of the Video Share session.

Bluetooth®

Connect wirelessly to headsets, speakers, computers, and more with Bluetooth technology.








1. Place your Bluetooth accessory into pairing mode.*
2. From standby mode, press the **Right Soft Key** for **Options** and then select **Bluetooth (2)**.
3. Select **Search New Device (3)**.
4. If Bluetooth is off, press  to turn it on.
5. Highlight your device and press . Enter the passcode* (typically "0000" – 4 zeroes) and press .
6. Select **Yes (1)** to connect to your device.

*Refer to your Bluetooth accessory's user guide for information about initiating pairing mode and the passcode.

Mobile Email

Take your email with you. With Mobile Email, you can quickly and easily access your email if your account is with one of these providers: Yahoo!®, AOL®/AIM, AT&T® Yahoo!, and Windows Live™ Hotmail.



1. From standby mode, press the **Right Soft Key** for **Options** and then select **Mobile Email (4)**.
2. Press  to select your service provider.
3. Enter your **Screen Name/ID** or **Email**, followed by your **Password**. Then press the **Left Soft Key** for **Sign In**.
4. Select a message and press  to download its contents.
5. Press  to delete the message, or press the **Left Soft Key** for additional options.






All providers may not be available on all devices. Yahoo! and the Yahoo! logo are trademarks and/or registered trademarks of Yahoo! Inc. AOL, America Online and the Triangle Logo are registered trademarks of America Online. Windows Live and the Windows logo are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.


Trademarks are property of their respective owners.

Instant Messaging

If you subscribe to an IM service such as AIM®, Windows Live™, or Yahoo!®, you can take the fun of IM on the go with your wireless phone.




1. From standby mode, press **right** on the **Navigation Key**.
2. Press  to select an IM community, then choose **Sign In (1)**.
3. Enter your **Screen Name/ID** or **Email**, followed by your **Password**. Check the **Auto-Sign In** box to be automatically connected in the future. Press the **Left Soft Key** for **Sign In**.
4. Select a contact currently online and press .
5. Enter your message, and then press  to send.
6. To end, press the **Right Soft Key** for **Options** and select **End Conversation (6)**.



Note: When you receive an incoming instant message, a “new message” icon similar to this one  will appear on the screen.


Trademarks are property of their respective owners.

MEDia™ Net





With MEDia Net, you can get the information that is important to you at a glance. Your local weather, your teams' scores, and your movie theaters are all just a few clicks away.

1. From standby mode, press .
2. Select the content you want to view and press .




Personalize Your MEDia Net Home Page

1. From the MEDia Net home page, scroll to **EDIT** and press .
2. Select the content you would like added or deleted from the MEDia Net home page and press .


Or, Personalize Your Home Page from Your PC


1. Go to att.com/mymedianet from your PC.
2. Enter your mobile phone number and start choosing content to add to your home page.
3. Click "Update Now" to save your changes.

Multitasking




Multitask simultaneously with voice and data – browse the web, make calls, play games, send and receive messages, and listen to music. All at once.

1. If you're involved in one task and want to launch another, press the **Key** and then the **Left Soft Key** for **Menu**. You can then select another task.
2. To switch among multiple tasks, just press the **Key** to display the task icon bar on the bottom of the screen. Select another task icon and press .




Note: If you get a call while in another task (except playing music), you can accept the call and then return to the task while you're talking.

Downloadable Fun





Whether you are into the latest hits or the classics, let your phone reflect your style with downloadable ringtones, Answer Tones™, and graphics. Or entertain yourself and those around you with the most popular downloadable games and applications.

Access AT&T Mall

1. From standby mode, press the **Left Soft Key** for **Menu** and then select **AT&T Mall (5)**.
2. Select **Shop Tones (1)**, **Shop Games (2)**, **Shop Graphics (3)**, **Shop Multimedia (4)**, **Shop Applications (5)**, or **Shop Videos (6)**.
3. Once connected, select a category and press .



Access Cool Games

1. From standby mode, press **left** on the **Navigation Key**.
2. Press  to select **Games (1)**.
3. Select a game to play by pressing , or shop for additional games at AT&T Mall.

Optional Accessories

Accessories for productivity, convenience, and fashion are available at att.com/wireless.



Headset



Vehicle Power Charger



USB Data Cable



Carrying Case



Bluetooth® Headset



microSD™ Card