

en-GB



read me

*Caution: before using your phone, please read the safety, regulatory and legal information provided with your product.*







## International SAR Compliance



This product meets the applicable national or international RF exposure guidance (SAR guideline) when used normally against your ear, or when worn or carried, at a distance of 1.5 cm from the body. The SAR guideline includes a considerable safety margin designed to ensure the safety of all persons, regardless of age and health.



To view the SAR values for your phone, visit <https://motorola.com/sar>. To view the information on the web, visit [www.motorola.com/rfhealth](http://www.motorola.com/rfhealth).



## At a glance

Let's get started. We'll guide you through startup and tell you about your phone.

**Note:** software updates happen frequently, so your phone may look a little different.



## Remove the back cover

If you need to insert SIM and memory cards, remove the back cover.

**Caution:** don't use tools to remove the cover—doing so may damage your battery or your phone.

### Take off the back cover.

1. Turn your phone upside down. Put your fingernail in the notch on the bottom corner.
2. Press your thumb in the centre of the back cover.
3. Pry the cover off.




## Remove the battery & put in cards

**Caution:** make sure you use the correct size SIM cards and don't cut the SIM cards. Don't use tools to remove the cover-doing so may damage your battery or your phone. Both of the card slots support 4G/3G/2G data services, but you can enable only one SIM card for data connection at a time.

Remove the battery.



Put in the SIM & optional memory cards.



1. SIM 1
2. SIM 2
3. microSD (optional)

microSD




Micro SIM

## Put on the cover & power on

Insert an optional memory card. Put on the back cover. Charge your phone fully and turn the power on. Then select your language and follow the screen prompts to get started.

**Put in the battery & put on the cover.**



**Charge up & power on.**




**Note:** Fully charge your phone before using it.

Press & hold Power until the screen lights up.


## Home screen & settings


From the Home screen, you can explore apps, check notifications, speak commands and more.


- **Add a shortcut:** tap Apps (⋮), tap and hold an app, then drag it to your home screen.
- **Settings:** to change your Wi-Fi, display brightness, and more, swipe the status bar down with two fingers. To open more settings, tap ⚙️.



## Photos

From the Lock screen, swipe  up to take crisp, clear photos.

- **See it:** swipe left for your photo gallery.
- **Share it:** view a photo or video from your gallery, then tap .









## Help & more

Get answers, updates and info:

- **Help is here:** tap Apps  →  **Help** to get walk-through tutorials, how-tos or FAQs, right on your phone.
- **Everything Moto E:** get software, user guides, and more at [www.motorola.com/mymotoe](http://www.motorola.com/mymotoe).
- **Get apps:** tap Apps  →  **Play Store** to buy and download apps.
- **News:** here's how to find us:
  -  YouTube™ [www.youtube.com/motorola](http://www.youtube.com/motorola)
  -  Facebook™ [www.facebook.com/motorola](http://www.facebook.com/motorola)
  -  Twitter [www.twitter.com/moto](http://www.twitter.com/moto)
  -  Google+™ [www.google.com/+Motorola/posts](http://www.google.com/+Motorola/posts)





## Battery safety

Before assembling, charging or using your mobile device for the first time, please read the important product safety and legal information provided with your product.

If your mobile device becomes unresponsive, try a reboot — press and hold the Power button until the screen goes dark and your device restarts.

Your mobile device uses a removable battery. Only use Motorola Original batteries for safety and best performance.

### Warning:

- Don't use tools, sharp objects or excessive force to insert or remove the battery. This may damage the battery and may cause burning and injury.
- Don't try to take apart or fix your battery. This may damage the battery and may cause burning and injury.
- Don't crush, bend or expose your battery or mobile device to heat or liquid. This may damage the battery and may cause burning and injury.

## Caution about high volume usage

**Warning:** to prevent possible hearing damage, do not listen at high volume levels for long periods.



## Disposal & recycling



Help do your part! Please don't dispose of mobile devices or electrical accessories (such as chargers, headsets or batteries) with your household waste. Product packaging and product guides should only be disposed of in accordance with national collection and recycling requirements. For details on approved national recycling schemes and Motorola recycling activities, go to: [www.motorola.com/recycling](http://www.motorola.com/recycling).



## Usage

this phone supports apps and services that may use a lot of data, so make sure your data plan meets your needs. Contact your service provider for details. Certain apps and features may not be available in all countries.





## Copyright & trademarks

Certain features, services and applications are network-dependent and may not be available in all areas; additional terms, conditions and/or charges may apply. Contact your service provider for details.

All features, functionality and other product specifications, as well as the information contained in this guide, are based upon the latest available information and believed to be accurate at the time of printing. Motorola reserves the right to change or modify any information or specifications without notice or obligation.




**Note:** the images in this guide are examples only.

MOTOROLA, the stylised M logo, MOTO and the MOTO family of marks are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. Google, Android, Google Play and other marks are trademarks of Google Inc. microSD Logo is a trademark of SD-3C, LLC. All other product or service names are the property of their respective owners.

© 2016 Motorola Mobility LLC.

Product ID: Moto E<sup>3</sup> (Model XT1706)

Manual number: 70114435





[motorola.com](http://motorola.com)



70114435



Printed in China