


**LYF WIND 6
(LS-5009)
Quick Start Guide**

Start Here

1

Phone overview



Knowing the Keys

Key	Function
Power Key	Press and hold to power on, or power off. Press to turn off or on the screen display.
Home Key	Touch to return to the Home Screen from any application or screen.
Menu Key	Touch to get the options for the current screen. Touch and hold to switch between recent apps.
Back Key	Touch to go to the previous screen.

Key	Function
Volume Up/ Down	Press or hold to turn the volume up or down.

Getting started

Please make sure that the phone is powered off before proceeding.

1. Open battery cover



2. Install SIM cards & memory card



3. Install battery



4. Install battery cover



Screen

LS-5009 features a large 12.7cm which makes your phone look fascinating.

Screen lock

You can increase the security of your phone by selecting screen lock .Screen lock settings can be found under "Settings">"Security"> "Screen lock".

Customize home screen

In standby mode, touch and hold an empty area to add/set wallpapers. To customize the home screen, you can move/remove/add items.

Camera

LS-5009 is equipped with a 5 MP front camera and a 5 MP rear facing camera, which are designed for you to share wonderful moments with friends and family.

Adjust focus, exposure, zoom in or zoom out, switch between cameras and switch between the functions by flipping the icon on the screen.

Internet

You can enjoy network by selecting 4G, 3G, WLAN, and GSM. Enjoy music, videos, apps and news anywhere and anytime as you like.

Make a call

You can make a call under the interface of Call log, contacts, favorites, message (which contains a phone number). In standby mode,

8

press call key to make a call.

Messaging

Touch and hold the text box to select an input method. You can insert smileys, pictures, audio or video files and send to multiple recipients.

Email

The email app enables you to read, compose and send emails, and is configured to work with all the major email providers. LS-5009 supports multiple account mode, and you won't miss any email.

Music

LS-5009 supports various music formats (MP3, MIDI, WAV, AMR, AAC, AAC+), different sound effects and categorizes your files on the basis of Artists, Albums, Songs &

Playlists.

Videos

Enjoy a visual feast in a variety of video formats (**mp4, avi, mkv, wmv**), please choose LS-5009. You may trim, mute and share a video.

Photos

You will find it very easy to view all the photos. Flick right or left to move among images. Double-tap or pinch the photo to zoom. You may edit, rotate, crop share, and print a photo (**Jpg/gif/png**).

Intelligent keyboard

LS-5009 automatically corrects and suggests words as you type, and it also

10

supports pictures and audio input.

Cut, copy, and paste

Touch and hold text content to bring up the magnifying glass, and then slide your finger to move the insertion points. Then tap to cut, copy, or paste. It is very easy to copy text from web pages, email, or text messages.

Map

You can view satellite images or street maps with detailed route instructions just as you are walking in the street. The Map app can be used to locate yourself, view real-time traffic conditions, pedestrian, bus routes or car driving route instructions.

Extending Battery Life

Few points to improve battery life.

- Turn OFF radio services i.e. Wi-Fi, Bluetooth and GPS, when not needed.
- Keep screen brightness on Auto Mode.
- Use Bluetooth tethering or USB tethering (when you have a cable) instead of portable Wi-Fi hotspot to share your phone's data service.
- From the home screen, hold the menu key to close the recent apps running in background.

Note:

Due to non-usage of Phone for long time battery may be drained out and it needs to be connected with charger and allow battery to charge about 30-40 minutes in off state. If still the problem persists, suggested to visit the nearest Device Care Centre.

Correct disposal

- Do not dispose off your mobile and its battery in fire.

- Do not dispose your mobile with the regular waste.
- For proper disposal please contact customer care.



This marking on the product, accessories or literature indicates that the product and its electronic accessories (e.g. charger, headset, USB cable) should not be disposed of with other household waste. This product is RoHS compliant.



This marking on the battery, manual or packaging indicates that the batteries in this product should not be disposed of with other household waste.

Safety information

Read all safety information before using the device to ensure safe and proper use.

**Warning**

Following the warning information provided below to prevent incidents such as fire or explosion

- Do not expose the device to physical impact or damage.
 - Do not carry your device in your back pockets or on your waist.
 - Store spare batteries in an appropriate protective case.
- Use manufacturer-approved batteries, chargers, accessories, and supplies
- Prevent the multipurpose jack and battery terminals from contacting conductive elements, such as metal or liquids.
- Do not touch the device with wet hands. **Also, do not use the device in humid environments, such as rest rooms, or**

during water-based activities, such as swimming.

- If any part of the device is cracked or broken, or if the device becomes very hot, stop using the device immediately and take it to a Reliance Service Centre.
- Do not turn on or use the device when the battery compartment is exposed

Following the warnings below to prevent injury to people or damage to the device

- Do not allow children or animals to chew or suck the device.
- Do not poke eyes, ears, or other body parts with the device or insert the device into the mouth
- If the device has a camera flash or light, do not use it close to the eyes of people or animals.
- Do not store your device in very hot or

very cold areas.

- Do not store your device near or in heaters, microwaves, cooking equipment, or high pressure containers
- Keep your device dry
- Do not use your device outdoor during a thunderstorm
- Comply with all safety warnings and regulations regarding mobile device usage while operating a vehicle



To prevent possible hearing damage when using a headset, do not listen to sound at high volume for long periods

Specific Absorption Rate (SAR) Certification information

Precautions:

16

Use a wireless hands-free system
(headphone, headset) with a low power
Bluetooth emitter

Make sure the cell phone a low SAR

Keep your calls short or send a text
message (SMS) instead. This advice applies
especially to children, adolescents and
pregnant women.

Use cell-phone when signal quality is good.

People having active medical implants
should preferably keep the cell phone at
least 15cm from the implant

**THIS DEVICE MEETS INTERNATIONAL
GUIDELINES FOR EXPOSURE TO RADIO
WAVES.**

Your mobile is designed not to exceed the
limits for exposure to radio waves
recommended by international guidelines.
The guidelines were developed by an

Independent scientific organization (ICNIRP) and include a substantial safety margin designed to assure the safety of all persons, regardless of age and health

The radio wave exposure guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit for mobile devices is 1.6W/Kg.

The highest SAR values under the ICNIRP guidelines for this device model are:

Maximum SAR for this model and Conditions under Which it was recorded	
Head SAR	1.194W/kg
Body-worn SAR	1.420W/kg

Body-worn SAR testing has been carried out

at a separation distance of 1.5 cm. To meet RF exposure guidelines during body-worn operation, the device should be positioned at least this distance away from the body

Please contact in case of help:

Customercare email id: care@mylyf.com

Customercare Tollfree phone number -
1800-890-9999